

TORCTOOL

TOOL MODEL: TTX-1

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	186	26	252	104
1600	198	27	269	110
1800	223	31	302	124
2000	247	34	335	138
2200	273	38	370	152
2400	299	41	405	165
2600	324	45	440	179
2800	350	48	475	193
3000	376	52	509	207
3200	402	56	544	220
3400	427	59	579	234
3600	453	63	614	248
3800	479	66	649	262
4000	505	70	684	276
4200	530	73	719	290
4400	556	77	754	303
4600	582	80	788	317
4800	607	84	823	331
5000	633	87	858	345
5200	658	91	892	358
5400	684	95	927	372
5600	709	98	962	386
5800	735	102	996	400
6000	760	105	1031	414
6200	786	109	1066	427
6400	812	112	1101	441
6600	838	116	1137	455
6800	864	120	1172	468
7000	890	123	1207	482
7200	916	127	1242	496
7400	942	130	1277	510
7600	967	134	1311	524
7800	993	137	1346	538
8000	1019	141	1381	552
8200	1045	144	1416	565
8400	1071	148	1452	579
8600	1097	152	1487	593
8800	1123	155	1522	607
9000	1149	159	1558	620
9200	1174	162	1592	634
9400	1200	166	1626	648
9600	1225	169	1661	662
9800	1250	173	1695	676
10000	1276	176	1729	690