

TORCTOOL

TOOL MODEL: TTX-21 SN: TX21EA1238-045
PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	2807	388	3805	104
1600	2999	415	4065	110
1800	3384	468	4587	124
2000	3768	521	5108	138
2200	4165	576	5647	152
2400	4562	631	6185	165
2600	4959	686	6723	179
2800	5356	741	7261	193
3000	5753	796	7799	207
3200	6131	848	8311	220
3400	6508	900	8822	234
3600	6885	952	9334	248
3800	7263	1004	9845	262
4000	7640	1057	10357	276
4200	8031	1111	10886	290
4400	8421	1165	11416	303
4600	8812	1219	11946	317
4800	9203	1273	12475	331
5000	9593	1327	13005	345
5200	9987	1381	13538	358
5400	10380	1436	14071	372
5600	10773	1490	14604	386
5800	11167	1544	15138	400
6000	11560	1599	15671	414
6200	11954	1653	16204	427
6400	12347	1708	16738	441
6600	12741	1762	17272	455
6800	13135	1817	17805	468
7000	13528	1871	18339	482
7200	13937	1927	18893	496
7400	14346	1984	19447	510
7600	14754	2041	20001	524
7800	15163	2097	20555	538
8000	15572	2154	21109	552
8200	15944	2205	21614	565
8400	16317	2257	22119	579
8600	16690	2308	22625	593
8800	17062	2360	23130	607
9000	17435	2411	23635	620
9200	17828	2466	24168	634
9400	18221	2520	24700	648
9600	18614	2574	25233	662
9800	19007	2629	25766	676
10000	19400	2683	26299	690