

TORCTOOL

TOOL MODEL: TTX-3

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	449	62	609	104
1600	481	67	652	110
1800	545	75	739	124
2000	608	84	825	138
2200	671	93	909	152
2400	733	101	994	165
2600	796	110	1079	179
2800	858	119	1163	193
3000	920	127	1248	207
3200	984	136	1334	220
3400	1047	145	1420	234
3600	1111	154	1505	248
3800	1174	162	1591	262
4000	1237	171	1677	276
4200	1301	180	1764	290
4400	1366	189	1851	303
4600	1430	198	1938	317
4800	1494	207	2025	331
5000	1558	215	2112	345
5200	1622	224	2199	358
5400	1687	233	2287	372
5600	1752	242	2375	386
5800	1816	251	2462	400
6000	1881	260	2550	414
6200	1946	269	2638	427
6400	2010	278	2725	441
6600	2075	287	2813	455
6800	2140	296	2900	468
7000	2204	305	2988	482
7200	2269	314	3076	496
7400	2334	323	3164	510
7600	2398	332	3251	524
7800	2463	341	3339	538
8000	2528	350	3427	552
8200	2593	359	3515	565
8400	2658	368	3603	579
8600	2723	377	3691	593
8800	2788	386	3780	607
9000	2853	395	3868	620
9200	2919	404	3956	634
9400	2984	413	4045	648
9600	3050	422	4134	662
9800	3115	431	4223	676
10000	3180	440	4311	690